



## Candle Making Instructions: How to Make Container Candles Using Blended Waxes BW-917

### Candle Making Supplies:

- 1 lb. of BW-917
- 1-2 color dye chips or a few drops of liquid dye
- 1 to 1 1/2 oz. candle fragrance oil
- HTP 104 wicks, pre-waxed and tabbed (for 4 oz. tins) or HTP 1212 (for 8 oz. tins, mason jars)
- Wick stickers
- heat resistant candle containers

### Candle Making Equipment:

- Digital scale
- double boiler (or old pan with water and melting/pouring pot)
- Candle-making Thermometer (or candy thermometer – you may also use a digital thermometer)
- measuring spoons
- long handled spoon or whisk

#### 1. How To Make Container Candles:

If you are using tins, use soap and hot water to clean and then dry. If you are using glass containers, it is highly recommended that you put them through the dishwasher. This will help avoid wet spots and give good adhesion to the glass. Alternately, you can wipe the bottoms of the contains with rubbing alcohol.

2. Melt wax in a double boiler over medium heat. As the wax melts, add dye. If you are using the dye chips, you may want to chop the chip up into small pieces to aid in melting. Stir to blend well.
3. Continue to heat wax to around 170°F until wax is fully melted. Remove from heat.
4. Add your fragrance oil and ***stir gently for a full two minutes.***
5. While wax is cooling, attach wick sticker to the bottom of the wick tab, and adhere to the inside of container, centering the wick in the middle of the container. TIP: Use a plastic straw – run your wick through it, pinch, attached to sticker, then attach to container and release.
6. Allow wax to cool to 160°F. Carefully and slowly pour melted wax into container. Pouring should be slow to avoid splashes and bubbles. Support the wick with a skewer or pencil, if necessary, and allow candle to cool completely.
7. After the candle is completely cooled, trim the wick and let "cure" for two weeks before burning.
8. While this wax is designed to be a 'one pour wax', sometimes under some conditions, you may get air pockets or uneven surface on your candle. If you are unhappy with the surface/tops of your candles and want a smoother look, you may want to reserve a small amount of wax and pour again after the top is mostly cooled, or use a heat gun to smooth them out.

Order any refills you need at [www.cierracandles.com](http://www.cierracandles.com). All ingredients underlined above can be purchased from us.

*Cierra Candle & Soap Making Supplies is not responsible for the performance of any of the recipes provided on our website or in kits. Testing is your responsibility. If you plan to resell any of the recipes we provide, it is your responsibility to adhere to all FDA regulations. If there are ingredients listed in a recipe that Cierra does not sell, we cannot offer any advice on where to purchase those ingredients.*